

## Assembly Instructions for Professional Dress Form

1. Unpack the metal base and install the 4 wheels in to the base.
2. Insert the main pole into the metal base till it rests on the pedal then fasten tightly with the provided T Bolts. (Please make sure the bottom part of the pole (see picture "adjustable spring") is inserted to the metal base.)
3. Take the body of Dress Form out of the box.
4. While stepping on the pedal, hold the 2 triangle like metal pieces on the top side of the pole together (see picture "triangle pieces"), then fit the pole and pieces into the pipe in the dress form body. (You will have to hold the 2 pieces together and step on the pedal at the same time to allow the pieces to fit together into the pole.)
5. Insert the dress form all the way into the pole, you can now adjust the height of the dress form by holding the pedal down and moving the dress form to the desired height.
7. Release the pedal to allow the dress form to stay in place.

**You are now ready to use your tailoring dress form.**

